



Teak Oil

Replaces oils lost in unpolished indoor/outdoor timber FOR GARDEN FURNITURE & TIMBER EXPOSED TO WARM OR WEATHERED CONDITIONS. Low sheen finish helps prevent splitting and gives light protection to softwood and hardwood garden furniture. Contains UV Filters, processed vegetable oils and solvents.

Technical Information

FORM	Viscous Liquid
COLOUR	Amber brown
ODOUR	Pine solvent
SPECIFIC GRAVITY	0.80-.0.90
FLASH POINT	38°C
COVERAGE	1L will cover 6-8 m ² depending on timber.

DIRECTIONS

Preparation

Lightly sand the wood along the grain and clean the surface with White Spirit. Shake the can before opening and apply using a brush/cloth or spray.

Application

Work the Teak Oil into the grain and ensure to wipe off any excess oil after 15 minutes. When treating outdoor furniture it is advisable to apply at the beginning or end of summer and to leave for 24 hours before re-coating. Apply as many coats as necessary to achieve a good finish. Regular use will prevent the grain turning grey and the surface splitting.

Caution

Application clothes and soiled rags may self ignite without warning. Dispose of safely to avoid fire risks, lay out in single layer to dry or wash out well in warm soapy water.

Cleaning

Clean tools, equipment etc. using white spirit, ecospirit or proprietary brush cleaner.

Storage

Teak Oil should be stored in closed containers protected from extremes of temperature.

Shelf Life

36 months in unopened containers.

Packaging

250ml, 500ml 1 Litre, 2,5 Litre, 5 Litre and 25 Litre packs.

VOC Info

(Cat: A,e; 400g/l 2010) Maximum Product Content = 395g per Litre.

Full Material Safety Data Sheets are available from www.birdbrand.co.uk or alternatively please contact us at the details given below.

Bird Brand ® is a registered trademark of R K & J Jones Limited, Southery Road, Feltwell, Thetford, Norfolk, IP26 4EH. UK.

Tel. 01842 828101 Fax. 01842 828171

Email: admin@birdbrand.co.uk